



FIG. 1






**FIG. 2**



**FIG. 3**



**FIG. 4**

FIG. 5


500

510

520

**Print** [?] [X]

**Printer**

Name:  hp Laser Jet 1300 PCL 6 [v] **Properties**

Status: Idle

Type: HP Laser Jet 1300 PCL 6

Where: LPT1: ☐ Print to file

Click for Printer Status: **NPI56B069**



**Page range**

☒ All  
☐ Current page ☐ Selection  
☐ Pages:

Enter page numbers and /or page ranges separated by commas. For example, 1,3,5-12

**Copies**

Number of copies:  [up] [down]

  ☒ Collate


Print what: **Document** [v] Print: **All pages in range** [v]


**Options...** **OK** **Cancel**


FIG. 6


**Print** [?] [X]


**Printer**


Name:  hp Laser Jet 1300 PLC 6 [v] **Properties**

Status:  \\FS1\HP8100N

Type:  \\FS1\HP8150\_PRINTER

Where:  \\FS1\HPCOLOR\_QUEUE

Comment:  \\FS1\RICOH-QUEUE



 hp Laser Jet 1300 PLC 6

**Page range**

☒ All  
☐ Current page ☐ Selection  
☐ Pages:

Enter page numbers and /or page ranges separated by commas. For example, 1,3,5-12

**Number of copies:**  [up] [down]

  ☒ Collate

Print what: **Document** [v] Print: **All pages in range** [v]

**Options...** **OK** **Cancel**


610

FIG. 7

510

**Print** [?] [X]

**Printer**

Name:  \\FS1\HP8150\_PRINTER [v] **Properties**

Status: Idle **710**

Type: HP Laser Jet 8150 Series PCL

Where: \\FS1\HP8150\_PRINTER

Click for Printer Status: **NPI56B071** ☐ Print to file



**Page range**

☒ All  
☐ Current page ☐ Selection  
☐ Pages:

Enter page numbers and /or page ranges separated by commas. For example, 1,3,5-12

**Copies**

Number of copies:  [v]

  ☒ Collate

Print what: **Document** [v] Print: **All pages in range** [v]

**Options...** **OK** **Cancel**

FIG. 8

**hp Laser Jet 1300 PCL 6 Document Properties** [?] [X] **812**

**Advanced** **Paper/Quality** **Finishing** **Effects**

**Print Task Quick Sets**

**Default Print Settings** [v] **Save** **Delete**

**Paper Options**


☐ Use different paper

**First Page**  
-----  
**Other Pages**  
**Back Cover**

Source is: **Automatically Select** [v]

Type is: **Plain** [v]

Click for Printer Status: **NPI56B069** **810**


 **Print Quality**

**600 dpi** [v]

☐ Economode  
[May Save Print Cartridges]

**Help**

**OK** **Cancel**



**FIG. 9**